

# Mounting instruction

**ECOFLEX® 10**

**UHF-Connector / Art. Nr.: 7377**



**1**



Cut off cable tail right-angled.

**2**



Remove 26 mm of the outer sheath with a knife.

**3**



Shorten the copper braid to 10 mm.

**4**



Bend copper braid backwards, Scarify and remove copper foil with a knife.

**5**



Remove 16 mm from the dielectric

**6**



Move connector sleeve over the cable. Screw housing onto the cable.

**7**



Solder the inner conductor carefully through the front hole..

**8**



Crew connector sleeve over the housing.