
IF SEM-2C(H)

for Volvo FH4B / FM4B / FMX4B trucks with SEM2 Module


BBM

(FH)





Location of the 5-pin green XC164 connector and BBM Module is under the fuse box in the center of the dashboard



1. Body Builder Module (BBM)

2. Fuse and relay box BBM

